


AIRPORT DIAGRAM

NEWARK INTL (EWR)
NEWARK, NEW JERSEY

ATIS ARR 115.7 134.825
 DEP 132.45
 NEWARK TOWER
 118.3 257.6
 GND CON
 121.8
 CLNC DEL
 118.85

Rwy 29 ldg 6502'
 Rwy 4L ldg 7460'
 Rwy 22R ldg 9560'
 Rwy 4R ldg 8790'
 Rwy 22L ldg 8210'

RWYS 4L-22R, 4R-22L, 11-29
 S191, T191, ST175, TT358, DDT873



AIRPORT DIAGRAM

NEWARK, NEW JERSEY
NEWARK INTL (EWR)