


# (MCOY6.ORL) MCCOY SIX DEPARTURE (PILOT NAV)

ORLANDO INTL (MCO)  
ORLANDO, FLORIDA

ATIS DEP  
120.525  
CLNC DEL  
134.7 341.7  
GND CON  
121.8 275.8  
ORLANDO TOWER  
118.45 288.15 (Rwy 17-35)  
124.3 253.5 Rwys 18L-36R, 18R-36L



NOTE: Turbojets only.  
NOTE: DME required.  
NOTE: Chart not to scale.

TAKE-OFF MINIMUMS: All Rwys, STANDARD.

(NARRATIVE ON FOLLOWING PAGE)

## DEPARTURE ROUTE DESCRIPTION

TAKE OFF RUNWAYS 17 AND 18L/R: Fly heading as assigned by ATC.  
Thence. . . .

TAKE OFF RUNWAY 35: Fly heading as assigned by ATC, cross ORL R-115 at or above 2600 feet, cross ORL VORTAC 090°/270° radial at or above 3000 feet.  
Thence. . . .

TAKE OFF RUNWAYS 36L/R: Fly heading as assigned by ATC, cross 2 DME south of the ORL VORTAC at or above 2300 feet, cross ORL VORTAC 090°/270° radial at or above 3000 feet. Thence. . . .

. . . . Maintain 5000 feet expect vectors to the Savannah transition. Expect further clearance to filed altitude ten (10) minutes after departure.

SAVANNAH TRANSITION (MCOY6.SAV): From over ORL VORTAC via ORL R-355 and CRG R-178 to CRG VORTAC, then via CRG R-007 and SAV R-198 to SAV VORTAC. Thence as filed.